



ThermOmegaTech®



INSTALLATION INSTRUCTIONS

1/2", 1" and 2" M/D

(also applicable to other "special order" mixing and diverting valves)

Refer to the M/D Product Fact Sheet for typical installation drawings.

For special applications not shown, consult factory.

These valves provide automatic mixing or diverting operation through the use of a thermostatic element inside the valve. This thermostatic actuator will control the mixing or diverting of the hot and cold fluids within the specified temperature range.

The M/D valves can be installed in any position consistent with the intended use. The operation of the M/D valves is not sensitive to orientation.

For mixing: cold inlet connects to C port, hot inlet to B port, A port is mixed outlet.

For diverting: connect inlet flow to A port, B port is the cold outlet, C port is the hot outlet.

Ports on some valves are marked "cold", "hot", "mix" which correspond respectively to C, B, A.

For most applications, pressure difference between the hot and cold ports should not exceed 10 psi.

M/D valves are suitable for controlling the flow of any fluids compatible with the materials of construction and factory related operating pressure and temperature limits.

M/D valves are not recommended for mixing steam and water; for steam/water mixing see bulletins describing the type STVM® valve.

For domestic hot water applications

Connect the cold water and hot water supplies to the correct connections on the valve, as shown on the Plumbing Diagrams for mixing or diverting on the product fact sheet.

Typically there should be no shut-off valves installed between the cold water supply line and the cold water connection on the M/D valve. A cold water service valve may be installed between the cold water supply line to the distribution system and the cold water line supplying both the water heater and the M/D valve.

In most plumbing applications, check valves should be installed on both the B and C ports, as shown on installation drawings.

WARRANTIES AND DISCLAIMERS:

Therm-Omega-Tech Inc. warrants this product to be free from defects in material and workmanship for a period of 36 months. Cost of replacement will be prorated on the basis of the issue date of each unit. Units found to be defective will be replaced on a one to one basis, FOB Warminster, PA USA. Installation and use of this product is outside the control of **Therm-Omega-Tech Inc.**; therefore, **Therm-Omega-Tech Inc.** disclaims any and all liabilities arising from its installation and or use, and furthermore, **Therm-Omega-Tech Inc.** makes no guarantees, either expressed or implied, in connection with its installation or use.

MD_IMI
REV: 10/07/14